

TO PAINT THE ORANGE IDENTIFICATION PANELS ON THE SPINE AND WINGS. MASK AND PAINT THE DESIGNATED AREAS ORANGE. THEN APPLY THE BORDER DECALS. THE DECALS ARE CAREFULLY DESIGNED TO FIT THE KINETIC ALPHA JET KIT.

NOTE THAT THE SAME AIRCRAFT (3501) CAN BE BUILT WITHOUT THE ORANGE IDENTIFICATION PANELS. PHOTOGRAPHS FROM 1980S AND EARLY 1990S DO NOT SHOW THE PANELS. IT LOOKS LIKE THE PANELS ARE A RELATIVELY RECENT ADDITION.

REFER TO THE SECOND PAGE FOR TOP AND BOTTOM VIEWS.

- **▲** SAND (FS33531)
- **DARK GREEN (FS34159)**
- **DARK EARTH (FS30118)**
- LIGHT BLUE (FS35526)
- **FLAT BLACK (FS37038)**
- **☐** INTERNATIONAL ORANGE (FS12197)

